

Kia Sportage Installation Instructions

PLEASE READ CAREFULLY BEFORE STARTING INSTALLATION

To safely lift and install this hardtop, you will need the assistance of at least one other person.

Follow the instructions and perform the steps in the sequence given. Short cuts to the directions may result in an unsatisfactory installation.

WARNING

The top on this vehicle is designed only for additional protection against the elements.

Do not rely on the top to contain occupants within the vehicle or to protect against intrusion of foreign objects, nor injury during an accident.

Make sure all brackets and screws are tight. Periodically check for tightness and retighten when necessary.

WEAR SEAT BELTS AT ALL TIMES

Parts included in the installation kit

- 2ea. Allen Head M6 x 45 Socket Cap Screws
- 1ea. Perimeter Seal 149"
- 4ea. 1" Washers
- 2ea. M6 Stay fast bolts
- 1ea. Rear Door Seal
- 1ea. Instruction Sheet



1. Unzip side windows. (both sides)



2. Remove side windows. (both sides)



3. Unzip rear window.



4. Remove rear window.



5. Pull down on soft top to disengage from flange. (both sides)



6. Pull forward to disengage soft top from front flange.



7. Remove soft top totally from vehicle.



8. Unscrew hoop assembly. (both sides)



9. Remove soft top hoop assembly.



10. Remove attach bolt. (both sides)



11. Remove attach bolt. (both sides)



12. Remove bolt from under rubber bumper. (both sides)



13. Remove all 5 flanges.
(both sides and top)



14. It should look like this when your done.



15. Next remove rubber trim from
perimeter flange.



16. Start here and install the
perimeter seal all the way
around. Bubble side facing out.



17. Install the top front side
pointing down, rear side up and
engage the front flange. Then
lower the rear of the top.



18. Locate the front hole and install the washer and M6 socket cap screw. Do not tighten.



19. Install rear washer with M6 stay fast bolt. Now tighten up all 4 bolts.



20. Remove old trim seal on tail gate.



21. Install new rear door seal. Trim to fit match old trim seal.

22. Lower the rear window and slowly close the gate. Make sure the gate is not rubbing.

**Your Done.
Enjoy !**